
SKU: 121 871

Model: A106000600

HAMPTON BAY

USE AND CARE GUIDE

RANCH PERGOLA



Questions, problems, missing parts? Before returning to the store, call Home Depot Customer Service 8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

01-800-004-6633

HOMEDEPOT.COM.MX

THANK YOU

Table of Contents

Table of Contents	2
Safety Information	
Warranty	
Pre- Assembly	
PIANNING ASSEMBLY	

Care and Cleaning	21
Assembly	7
Package Contents	5
Hardware Included	4

Safety Information

- More than four people are required for this assembly.
- 2. Some parts may contain sharp edges. Wear protective gloves.
- When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and usage.



WARNING: Keep all flame and heat sources away from this gazebo fabric. This gazebo is made with fabric that meets CPAI-84 specifications for flame resistance. It is not fire proof. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the gazebo fabric may render the flame-resistant properties ineffective.



DANGER: This unit is heavy! Do not assemble this item alone.



WARNING: While this gazebo is manufactured to withstand winds through only the supplied ground stakes, in areas subject to frequent severe weather, securing the gazebo to a deck, concrete patio or footings should be considered. Snow must be cleared off regularly during snowy days. Remove the snow at the top when it is thicker than 4 inches. In order to avoid damage, use a plastic snow rake to remove excessive snow and ice buildup from roof and keep away from falling debris.



CAUTION: Do not climb on top of the pergola. Falling off the pergola can result in serious injury, possibly even death.

Warranty

1 YEAR WARRANTY

WHAT IS COVERED

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of 1 year.

WHAT IS NOT COVERED

We do not reimburse for transportation of delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

Contact the Customer Service Team at 01-800-00-46633 or visit HOMEDEPOT.COM.MX.

Product Number: 2022300712

Pre-Assembly


PLANNING ASSEMBLY

Before beginning assembly of this product, make sure all parts are present. Compare parts with the Hardware Included and Package Contents lists. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.




NOTE: Tools and protective articles below are not provided.

TOOLS REQUIRED



IMPORTANT

Requires at least 4 people for the installation work. Approximate installation time: 1 hour.





HARDWARE INCLUDED


NOTE: Hardware not shown to actual size.

Part	Part Number	Description	Quantity
AA	H010020012	M6 X 20 Bolt	104+6
BB	H050030001	M6 Washer	132+7
CC	H050020017	M6 Spring washer	68+4
DD	H010020206	M6 X65 Bolt	12+1
EE	H010110016	M6 X15 Bolt	16+1
FF	H070010003	⊄ 8*180 Stake	8
W	H090010017	M6 Wrench	2

PACKAGE CONTENTS








Part	Part Number	Description	Quantity
А	P000600843	Top beam 1	6
В	P000600844	Top beam 2	6
С	P000400588	Curve beam 1	2
D	P000400589	Curve beam 2	2
E	P000500690	Curve beam connector	2
F	P000400590	Cross beam 1	2
G	P000400591	Cross beam 2	2
Н	P000500689	Cross beam connector	2
I	P005000239	Curve support 1	2
J	P005000240	Curve support 2	2
К	P005600157	Decoration	4
L1	P000200274	Post 1	2
L2	P000200275	Post 2	2
M1	P006100106	Stake cover	4
M2	P000100166	Stake base	4
N	P005700241	Canopy tube 1	2
0	P005700242	Canopy tube 2	2
Р	P005600159	Decoration 2	4
Q	P005600158	Decoration 1	4
R	P006400009	Canopy	1

Assembly

Attaching the Decoration


Attach the Decoration (K) on the Posts (L1&L2) using Bolts (AA) and Washers (BB). Tighten the bolts.







2 Attaching the Stake Covers and Stake Bases

□ Insert the Stake covers (M1) over the Posts (L1&L2). Attach the Stake bases (M2) to the bottom of the Posts (L1&L2). Tighten the bolts.








3 Assembling the Curve Beams


□ Insert the Curve beam connectors (E) into the Curve beams (C&D) using Bolts (AA), Washers (BB) and Spring washers (CC).



4

Assembling the Cross Beams


□ Insert the Cross beam connectors (H) into the Cross beams (F&G) using Bolts (AA), Washers (BB) and Spring washers (CC).




5

Attaching the Curve Beams

Attach the assembled Curve beams (C&D) to the Posts (L1&L2) using Bolts (AA), Washers (BB) and Spring washers (CC). Tighten the bolts.







6

Attaching the Cross Beams

Attach the assembled Cross beams (F&G) to the Posts (L1&L2) using Bolts (AA), Washers (BB) and Spring washers (CC). Tighten the bolts.








7 Connecting the Cross Beams


□ Attach the Décor (P&Q) on the Posts (L1&L2) using Bolts (AA) and Washers (BB). Tighten the bolts.












8 Attaching the Curve Supports


Attach the Curve supports (I&J) to the Posts (L1&L2) and Cross beams (F&G) using Bolts (AA), Washers (BB) and Spring washers (CC).





9 Connecting the Top Beams

□ Connect the Top beam 1 (A) with Top beam 2 (B) using Bolts (EE) and Washers (BB).










10 Attaching the Top Beams


Attach the assembled Top beams (A&B) to the Curve beams (C&D) using Bolts (DD) and Washers (BB).






Connecting the Canopy Tubes

Connect the Canopy tube 1 (N) with Canopy 2 (0) using Bolts (EE), Washers (BB) and Spring washers (CC).






Please contact 01-800-00-46633 for further assistance.

12 Inserting the Canopy Tubes

Insert the assembled Canopy tubes (N&O) into the Canopy (R).








13 Attaching the Canopy

Place the Canopy (R) over the pergola by attaching to the Posts (L1&L2) as shown.







14 Securing the Pergola

- □ Secure the pergola to the lawn using the Stakes (FF).
- □ It is recommended for anchoring on wood or concreate surface for more stability using setscrew (Purchased separately).







Care and Cleaning

- Steel components for this pergola are treated with rust inhibiting paint that protects it from rusting. However, due to the nature of steel, surface oxidation (rusting) will occur if these protective coatings are scratched. This is not a defect and thus not covered by the warranty. To minimize this condition, it is recommended to use care when assembling and handling the product to prevent scratching the paint. Should any scratching or damage occur, it is recommended to cover the scratch immediately with rust inhibiting paint (not included). Surface rust can also be easily removed with a very light application of regular cooking oil. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping onto deck or patio and caused damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.
- □ Do not use bleach, acid, or other abrasive cleaners on the roof or frame parts.
- Keep instruction manual for future reference.
- Keep the original packaging to store the pergola.
- □ Remove canopy during bad weather and windy conditions.
- □ When not in use, store in a cool, dry area.

HAMPTON BAY

Importer: Servicios Home Depot, S. de R.L de C.V. Ricardo Margain 605, Santa Engracial, San Pedro Garza Garcia, N.L. México C.P. 66267 Phone: 01 800 004 6633

Questions, problems, missing parts? Before returning to the store, call Home Depot Customer Service 8 a.m. - 7 p.m., EST, Monday- Friday, 9 a.m. - 6 p.m., EST, Saturday

01-800-004-6633

HOMEDEPOT.COM.MX

Retain this manual for future use.