


Item# 1005 052 002
Model# A210016100

HAMPTON BAY®

USE AND CARE GUIDE

WINDSOR SIDE TABLE - BROWN



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this side table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2
Important Safety Instructions.....	2
Warranty	2
Pre-Assembly	3
Planning assembly.....	3

Hardware Included.....	3
Package Contents	3
Assembly	5
Care and Cleaning	6

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children or disabled persons.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Some parts may contain sharp edges. Wear protective gloves.
4. Please count the parts before assembly.
5. Set up your furniture properly. Ensure that all parts are assembled properly and fully tightened as per instructions. When placing in the desired location, ensure that all legs are resting on the same surface. You may adjust the leg levelers as required to ensure that the item stands in a level position.

6. Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be re-tightened fully before additional use



DANGER: Keep children and parts away from the assembly area.



WARNING: To avoid destroying the finish, please handle the surface by using a soft cloth instead of your bare hands. Due to the nature of iron, surface oxidation (rusting) will occur if these protective coatings are scratched. We recommend immediate touch-up with rust inhibiting paint (not included).



CAUTION: Do NOT over tighten any of the bolts or nuts.

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of 3 years.

WHAT IS NOT COVERED

We do not reimburse for transportation of delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

Contact the Customer Service Team at 1-800-841-1350 or visit [www. Hamptonbay.com](http://www.Hamptonbay.com).

Production Number: 2022200026

Pre-Assembly


PLANNING ASSEMBLY

Before beginning assembly of this product, make sure all parts are present. Compare parts with the Hardware Included and Package Contents lists. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.




Part	Part Number	Description	Quantity
AA	H100010006	Bolt M6*15 with Washer	12+2
BB	H090030002	Wrench M6	1
CC	H090030009	Ratchet Wrench M6	1



NOTE: 1pc of Ratchet Wrench per Set.


PACKAGE CONTENTS



Part	Part Number	Description	Quantity
A	P002100351	Table Top	1
B	P005400432	Leg	4
C	P002200223	Bottom Shelf	1
D	P005300053	Leveling feet (Pre-assembled)	4


Pre-Assembly (continued)

OPTIONAL TOOLS TO AID ASSEMBLY (NOT INCLUDED)



IMPORTANT

This assembly requires one to two person. Approximate assembly time: 15~20 minutes.




Assembly

1 Attaching the Table Top and Legs

- Attach the legs (B) to the table top (A) using 8 bolts (AA). Use wrench (BB) or ratchet wrench (CC) to loosely tighten the bolts.



NOTE: Do not fully tighten the bolts.




2 Attaching the Bottom Shelf

- Attach the bottom shelf (C) to the assembly legs (B) using 4 bolts (AA). Use wrench (BB) or ratchet wrench (CC) to fully tighten all the bolts.



NOTE: To preserve the finish, place parts on a soft surface.



Care and Cleaning

- Before using, clean the side table completely with a soft dry towel.
- Do not use harsh abrasives or cleaners.
- When not in use, store in a cool, dry area.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-841-1350

HAMPTONBAY.COM

Retain this manual for future use.

For certification use only
Factory Model# A210016100

