


Item# 1001 485 902/ 1001 464 970

Model# A201001500/ A214000100

HAMPTON BAY[®]

USE AND CARE GUIDE

WINDSOR OTTOMAN



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-841-1350

WWW.HOMEDEPOT.CA

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this Ottoman. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2
Important Safety Instructions	2
Warranty	2
Pre-Assembly	3
Planning Assembly.....	3

Hardware Included.....	3
Package Contents	4
Assembly	5
Care and Cleaning	7

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Some parts may contain sharp edges. Wear protective gloves.
4. Please count the parts before assembly.
5. Set up your furniture properly. Ensure that all parts are assembled properly and fully tightened as per instructions. When placing in the desired location, ensure that all legs are resting on the same surface. You may adjust the leg levelers as required to ensure that the item stands in a level position.

6. Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be re-tightened fully before additional use.



DANGER: Keep children and parts away from the assembly area.



WARNING: To avoid destroying the finish, please handle the surface by using a soft cloth instead of your bare hands. Due to the nature of iron, surface oxidation (rusting) will occur if these protective coatings are scratched. We recommend immediate touch-up with rust inhibiting paint (not included).



CAUTION: Do NOT over tighten any of the bolts or nuts.

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of 3 years.

WHAT IS NOT COVERED

We do not reimburse for transportation of delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

Contact the Customer Service Team at 1-800-841-1350 or visit WWW.HOMEDEPOT.CA.

Production Number: 2021200026


Pre-Assembly

PLANNING ASSEMBLY

Before beginning assembly of this product, make sure all parts are present. Compare parts with the Hardware Included and Package Contents lists. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.


IMPORTANT

This assembly requires one person. Approximate assembly time: 15~20 minutes.




HARDWARE INCLUDED


NOTE: Hardware not shown to actual size.



AA



BB




CC

Part	Part Number	Description	Quantity
AA	H100010032	Bolt M6*40 with Washer	12+1
BB	H090030002	Wrench M6	1
CC	H090030009	Rachet Wrench M6	1

NOTE: 1pc of Rachet Wrench per Set

Pre-Assembly (continued)

PACKAGE CONTENTS



Part	Part Number	Description	Quantity
A	P00140032101	Side Panel	2
B	P001600089	Seat	1
C	P00380056801	Front/Back Panel	2
D	P001800045	Cushion	1
E	P005300055	Leveling Feet (Pre-assembled on A)	4


Assembly

1 Attaching the Back Panel and Side Panel

- Connect the back panel (C) and the side panels (A) using bolts (AA). Use the wrench (BB) or ratchet wrench (CC) to loosely tighten the bolts.



NOTE: Do not fully tighten the bolts, please pay attention to the direction of the panels (C).




2 Attaching the Front Panel

- Connect the front panel (C) and the side panels (A) using bolts (AA). Use the wrench (BB) or ratchet wrench (CC) to loosely tighten the bolts.



NOTE: To preserve the finish, place parts on a soft surface, please pay attention to the direction of the panels (C).




Assembly (continued)

3 Attaching the Seat

- Attach the seat (B) to the assembly side panels (C) using bolts (AA).
- Use the wrench (BB) or ratchet wrench (CC) to fully tighten the all bolts.




NOTE: To preserve the finish, place parts on a soft surface.



4 Placing the Cushion

- Place the Cushion (D) on the Seat (B) to complete the assembly.



Care and Cleaning

- ☐ Before using, clean the Ottoman completely with a soft dry towel.
- ☐ Do not use harsh abrasives or cleaners.
- ☐ When not in use, store in a cool, dry area.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-841-1350

WWW.HOMEDEPOT.CA

Retain this manual for future use.

For certification use only
Factory Model# A214000100